



## **Jinhua Jinglan Industry & Trade Co.,Ltd.**

Xiaoshun Town, Jindong District, Jinhua, Zhejiang, China

Tel: +86-0579-82955519 Fax: +86-0579-82955517 Email: [jhys8@126.com](mailto:jhys8@126.com)

### YSA2 Safety Spectacles for Occupational Use



#### **Description**

YSA2 eye-protectors are spectacles for occupational use with polycarbonate lenses and PC frames.

#### **Field of Use (Protection capabilities and performance characteristics)**

This product is intended for protection against low energy impact, as encountered in industry, laboratories, educational establishments, DIY activities, etc. which are likely to damage the eye or impair vision.

#### **Service life**

YSA2 safety spectacles should be replaced after three years in service.

#### **Storage and Maintenance**

Store this product in a soft carry bag or spectacle case when not using it.

Cleaning is recommended after each use. The product should be cleaned using a cloth moistened with warm soapy water and dried at room temperature. A suitable clean lens cleaning cloth may also be used.

Do not use petrol, chlorinated degreasing fluids, organic solvents or abrasive cleaning agents to clean any part of the equipment.

#### **Standards and Approval**

These safety spectacles are classed as Personal Protective Equipment (PPE) by the European PPE new regulation (EU) 2016/425 and have been shown to comply with this regulation through the Harmonised European Standard NF EN166:2002: SAFETY SPECTACLES.

#### **Use Limitation and warning**

1. Never modify or alter this product.
2. Do not use this product against hazards other than those specified in this document/product user instructions.
3. Scratched or damaged oculars should be replaced.
4. Materials which may come into contact with the wearer's skin could cause allergic reactions to susceptible individuals.



## **Jinhua Jinglan Industry & Trade Co.,Ltd.**

**Xiaoshun Town, Jindong District, Jinhua, Zhejiang, China**

**Tel: +86-0579-82955519 Fax: +86-0579-82955517 Email: jhys8@126.com**

5. Guards against high speed particles used on conventional eye glasses may result in shock and causing a danger to the user.
6. The compatibility of marking should be ensured.

### **Marking**

FRAME : YSA2 JJI CE EN 166 F XX/XX

GLASS : JJI 1 F

Model No. :YSA2

Manufacturer's identification :JJI

European standard number :EN166

Impact resistance :F (low energy impact 45M/S)

1: **Highest optical class**

XX/XX : the batch number

### **Manufacturer information**

Jinhua Jinglan Industry & Trade Co.,Ltd.

Xiaoshun Town, Jindong District

Jinhua City

Zhejiang Province

P.R.China

The EU Declarations of Conformity is available on website

URL: [www.cnjhjl.com](http://www.cnjhjl.com)

Test & Certification Notified Body

ALIENOR CERTIFICATION

ZA DU SANITAL 21 RUE ALBERT EINSTEIN 86100 CHATELLERAULT France – N°2754