

MICROSCOPIO BIOLOGICO BIOLOGICAL MICROSCOPE MICROSCOPE BIOLOGIQUE BIOLOGISCHES MIKROSKOP MICROSCOPIO BIOLÓGICO MICROSCÓPIO BIOLÓGICO

REF 31002

Modello / Model / Modèle Vorlage / Modelo / Modelo N-126

Fabbricante / Manufacturer / Fabricant / Hersteller / Fabricante / Fabricante: NINGBO YONGXIN OPTICS CO., LTD. No. 169 Mujin Road, Hi-tech Park Ningbo, China Made in China

Importato da / Imported by / Importé de / Importiert von / Importado de / Importado de: **Gima S.p.A.** Via Marconi, 1 - 20060 Gessate (MI) Italy gima@gimaitaly.com - export@gimaitaly.com www.gimaitaly.com



Index

SAFETY NOTE	
MAINTENANCE AND CARE	
1. COMPONENTS NAME	
2 ASSEMBLY	18
2.1 Assembly Diagram	
2.2 Assembly procedure	
3. ADJUSTMENT AND OPERATION	20
3.1 Adjustment set diagram	20
3.2 Adjustment and Operation	22
4. TECHNICAL SPECIFICATIONS	24
4.1 Main Specifications	24
4.2 Eyepiece and objectives	25
5. TROUBLESHOOTING GUIDE	26
5.1 Optical System	26
5.2 Mechanical System	27
5.3 Electrical System	27

Safety Note

- 1. Open the box carefully to avoid the accessories, like lens, dropping to ground or being damaged.
- 2. Do keep the instrument out of direct sunlight, high temperature or humidity, dusty and easy shaking environment. Make sure the stage is flat, horizontal and firm enough.
- 3. When moving the microscope, carefully carry it with the handle and the base.
- 4. Make sure the instrument is earthed, to avoid lighting strike.
- 5. For safety, be sure the main switch is in "O" (off) state and cut off the power supply before replacing the bulb or the fuse. If you replace the bulb during use or right after use, allow the lamp bulb and the lamp house to cool completely before touching. (Designated bulb: 1W S-LED)
- 6. Check the input voltage: be sure the input voltage which is signed in the back of the microscope is consistent with the power supply voltage, or it will bring a serious damage to the instrument.
- 7. Always use the power cord provided by Gima.
- 8. The electrical equipment of the microscope should be discard as electronic waste.

Maintenance and Care

- 1. All the lenses have been adjusted properly; do not dismount them by yourself please.
- 2. The nosepiece and coarse and fine focusing parts are so delicate that it is forbidden to disassemble them carelessly by yourself.
- 3. Keep the instrument clean, and do not pollute the optical element when wiping away the dust on the instrument.
- 4. The contaminations on the prism, like fingerprints and oil smudges, could be gently wiped with a piece of soft cloth or tissue paper, gauze which has been immersed in pure alcohol or ether. (Note that the alcohol and ether are highly flammable, do keep them away from the fire or potential sources of electrical sparks, and use them in a drafty room as possible as you can.)
- 5. Do not attempt to use organic solvents to clean the microscope components other than the glass components. To clean them, use a lint-free, soft cloth slightly moistened with a diluted neutral detergent.
- 6. When using, if the microscope is splashed by liquid, cut off the power at once, and wipe away the splash.



- 7. Do not disassemble any parts of the microscope, as this will affect the function or reduce the performance of the microscope.
- 8. Place the instrument in a cool, dry position. When not using the microscope, keep it covered with a dust cover. Make sure the lamp socket is cool before covering the microscope.

1. Components Name





2. Assembly

2.1 Assembly Diagram

The following figure shows the installation sequence of the components. The number in the figure shows the assembly steps.

- Before installing, be sure every components is clean, do not score any parts or glass surface.
- Keep well with hexagon wrench provided. When changing the components, you will need it again.

10X or 16X Eyepiece 2 Binocular viewing head 1 3 ₽. (**)** Objective Main body Power cord

2.2 Assembly procedure

Installing binocular viewing head (fig. 1-2)

Insert the binocular viewing head into the microscope head and turn it to a proper position, then tight it.





fig. 1

fig. 2

Installing the eyepiece (fig. 3-4)

Insert the eyepiece into the eyepiece tube until they are against each other (fig. 4).



fig. 3



Installing the objective (fig. 5-6)

- 1. Adjusting the coarse focus knob until the support device of the mechanical stage reaches its low limit position.
- Screw the lowest magnification objective into the nosepiece from the left or the right side, then revolve the nosepiece clockwise and mount other objectives by the sequence of low to high magnification.
 - Installing objective this way will make the change of magnification to be easier during using.
- Clean the objective regularly, for lens is susceptible to dust.
- When operating, use 10x magnification objective to search and focus specimen firstly, then replace with higher magnification objective if necessary.
- When replacing the objective, slowly turn the nosepiece until you hear "clicked", that means the objective is in place.







fig. 5



Connecting the Power Cord (fig. 7-9)

The cable and cords are vulnerable when bent or twisted, never subject the power cord to excessive force.

- 1. Set the main switch 1 to "0" (off) state before connecting the power cord.
- 2. Insert the plugs 2 into the power jack 3 of the microscope safely.
- 3. Plug the power cord 4 into the power supply receptacle 5. Make sure the connection is well.
- Do use the supplied power cord all the time. If lost or damaged, select the same standard cord, please.
- A wide range of voltage, like 100V~240V, is acceptable for this microscope.











Replacing the fuse (fig. 8-9)

Do remember to set the main switch **1** to the state "0" (OFF) and unplug the power cord before replacing the fuse. Rotate the fuse out of the holder **3**, replace with a new fuse, then rotate it back to the holder again.



3. Adjustment and Operation

3.1 Adjustment set diagram



Right Fine Focus Knob

fig. 10





fig. 11

3.2 Adjustment and Operation

Brightness Adjustment (fig. 12-13)

1. Connect the power cord and set the main switch 1 to " - "state (ON).

2. Turning the brightness adjustment knob 2.





fig. 12

fig. 13

Placing the Specimen (fig. 14) 1. Place the specimen the center of the mechanical stage and use the stage clips to clamp it.

- 2. Turn the portrait and lateral adjustment knob **1** of the mechanical ruler, move the specimen to the required position.
- Be careful when changing the objective. If you finish the observation with the short working distance objective, and want to change another one, becareful of not letting the objective touch the specimen.





fig. 14



Focusing the Specimen (fig. 15)1. Focus the specimen with 10x objective. To avoid the objective touching the specimen during focusing, you should raise the mechanical stage to let the specimen close to the objective at first, then slowly separate them to bring the specimen to focus.

Turn the coarse focus knob 1 conversely to lower the specimen and search images in the 10×ocular simultaneously, and then use the fine knob 2 to focus. After that, you can replace with other magnification objectives safely, and focus without the risk of damaging the specimen.

• To make the observation more convenient, you can use the locking set **3** to fix the stage in a vertical direction.

Condenser Adjustment (fig. 16)

Turn the condenser focus knob **1** to move the condenser up and down. Raise the condenser when using the high magnification objective, and descend it when using the low magnification one.

- 1. Focus the specimen with 10x objective.
- 2. Adjust the condenser focus knob **1** to get a clear image of the field iris diaphragm.
- 3. Turn the condenser centering knobs **2** to center the image of field iris diaphragm in the field of view.
- The condenser and the objective are coaxial. It has been adjusted before leaving factory, so the user needn't to adjust them by self
- The highest position of the condenser has been adjusted too. It also needn't any user's operation. (The top surface of the condenser is 0.03 mm - 0.4 mm lower than the stage top surface.)

Aperture Iris Diaphragm Adjustment (fig. 17)

Turn the aperture iris diaphragm stick **1** to adjust the aperture iris diaphragm.

• The aperture iris diaphragm is designed for the adjustment of the numerical aperture, not for the brightness.

Generally, setting the aperture iris diaphragm to 70- 80% of the N.A. of the objective in use will provide an image with good contrast. If you want to observe the image of the aperture iris diaphragm, remove one eyepiece and look through the tube. You will see a dark circle encroaching on the bottom of the tube.

Adjusting the Interpupillary Distance (fig. 18)

The interpupillary distance range: 47mm-78mm While looking through the eyepieces, move both eyepieces round until the left and right fields of view coincide completely.



fig. 16







fig. 18

Adjusting the Diopter (fig. 19)

- 1. Turn the eyepiece **1** to adjust the diopter while looking through it.
- The diopter range of the eyepiece is ±5 diopter. The number aligned to the line on the viewing head is the diopter in use.

Adjusting the tension adjustment collar (fig. 20)

Turn the tension adjustment collar **1** with your fingers. When the collar is turned in the direction of the arrow, the tension of the coarse adjustment knob **2** increases. Turning the collar in the opposite direction decreases the tension.

If the nosepiece descends on its own or if the specimen gets out of focus quickly even when it is brought into focus using the fine adjustment knob **3**, it means the tension of the coarse adjustment knob is too low. Turn the collar in the direction of the arrow to increase the tension.



fig. 19





4. Technical Specifications 4.1 Main Specifications

Optical System	Limited optical system/Infinite optical system	
Viewing Head	Seidentopf Binocular Head, 30° Inclined, Interpupillary Distance 47-78 mm	
Eyepiece	WF 10X/20 and P16X/11	
Nosepiece	Backward Quadruple Nosepiece	
Objective	Achromatic Objective/Infinite Semi-plan Objective 4×, 10×, 40×, 100×	
Focusing	Coaxial Coarse and Fine Adjustment, Moving Range 0.002mm, Fine Division 20mm	
Condenser	Abbe Condenser, NA1.25	
Stage	Rackless Double Layers Mechanical Stage 150×139mm, Moving Range 75×52mm	
Illumination	1W S-LED	

4.2 Eyepiece and objectives

Achromatic Objective

Magnification	Numerical Aperture NA	Focal Length (mm)	Focal distance (mm)	Working Length (mm)	Objective
4×	0,10	0,17	31,05	37,5	dry
10×	0,25	0,17	17,13	7,316	dry
40×	0,65	0,17	4,65	0,632	dry
100×	1,25	0,17	2,906	0,198	oil

Infinite Semi-plan Objective

Magnification	Numerical Aperture NA	Focal Length (mm)	Focal distance (mm)	Working Length (mm)	Objective
4×	0,10	0,17	45	16.8	dry
10×	0,25	0,17	18	5.8	dry
40×	0,65	0,17	4.5	1.43	dry
100×	1,25	0,17	1.8	0.13	oil

Eyepiece

Eyepiece	Magnification	Focal Length (mm)	Field of View (mm)
Wide field eyepiece	10×	24,95	Φ18
Wide field eyepiece	10×	25	Φ20
Wide field eyepiece	16×	15.58	Φ11

Total Magnification

Eyepiece	10×	10×	10×	10×
Objective	4×	10×	40×	100×
Total Magnification	40×	100×	400×	1000×

Eyepiece	16×	16×	16×	16×
Objective	4×	10×	40×	100×
Total Magnification	64×	160×	640×	1600×

5. Troubleshooting Guide 5.1 Optical System

TROUBLE SOLUTION CAUSE 1. The edge of the field of The nosepiece is not in the locat-Locate the nosepiece properly view is dark or the brighted position (objective and light where it clicks ness is not uniform path not coaxial) The surface of the lamp becomes Change a new lamp bulb black A lens (the objective, condenser, Clean it thoroughly eyepiece or collector) is dirty. 2. Dirt or dust is visible in the Dirt/dust on the specimen Replace with a clean specimen field of view Dirt/dust on the eyepieces Clean them 3. Visibility is poor Specimen is not covered Add cover glass on it Image is not sharp: The thickness of the cover glass is Use standard cover glass with Contrast is poor: not suitable thickness of 0.17mm Details are indistinct Turn it over Specimen is placed reversely Dry objective has oil on it. (espe-Wipe the oil cially for 40X objectives) A lens (the objective, condenser, Clean it eyepiece or collector) is dirty. Immersion oil is not used with the Use specified oil 100x objective Air bubbles existed in the immer-Eliminate the bubble sion oil The aperture iris diaphragm is Adjust the aperture iris diastopped down too far phragm properly Dirt or dust on the evepiece Clean it Center the condenser with the 4. One side of image is Condenser is not properly cenblurred tered centering screw The nosepiece is not properly en-Engage the nosepiece properly gaged The specimen is not clamped Clamp it with stage clips 5. The brightness is not The aperture iris diaphragm is too Adjust it properly enough small The condenser is too low Adjust it properly A lens (the objective, condenser, Clean it eyepiece or collector) is dirty.

TROUBLE	CAUSE	SOLUTION
1. Field of view of one eye does not match that of the other	Interpupillary distance is incorrect	Adjust interpupillary distance
2. Observation is tiring	The diopter is not proper	Adjust the diopter properly
	The brightness of the illumination is not proper for eyes	Adjust the lamp voltage

5.2 Mechanical System

5.3 Electrical System

TROUBLE	CAUSE	SOLUTION
1. The bulb cannot light	No power supply	Check the power cord connec- tion
	The pin of the bulb doesn't insert properly	Insert the pin deeply
	The bulb broken	Replace with a new one
2. The bulb burns out suddenly	The bulb is not the specified one; The voltage is too high	Use the specified bulb; lower the voltage
3. The illumination is not bright enough	The voltage is too low	Raise the voltage
4. Image flicks	The bulb is about to burn out	Replace with a new one
	The bulb is not inserted deeply	Check its connection

	Symbols				
\triangle	Caution: read instructions (warnings) carefully	E	Follow instructions for use		
CE	Product complies with European Directive	\sim	Date of manufacture		
×	Keep away from sunlight	Ţ	Keep in a cool, dry place		
REF	Product code	LOT	Lot number		
X	WEEE disposal				



Disposal: The product must not be disposed of along with other domestic waste. The users must dispose of this equipment by bringing it to a specific recycling point for electric and electronic equipment.

GIMA WARRANTY TERMS

The Gima 12-month standard B2B warranty applies.