

Figure 18 Denote value setting interface

(5)Exit

Under (Data management) , select “Exit” to return to (Menu) interface.

c.Settings

Under (Menu) interface, select “Settings” to enter (Settings) interface as shown in Fig.19. Under this interface, settings of language, Bluetooth on/off, time and calibration, and view device information can be realized.




Figure 19 Setting interface



Figure 20 Language setting interface

(1) Language setting

Under (Settings) interface, select “Language” to enter (Language setting) interface as shown in Fig.20. Select “English”, the device language will be English, select “中文”, the device language will be Chinese, after selected, it will automatically return to (Settings) interface.

(2) Bluetooth

Move selection toolbar to “Bluetooth”, press “Confirm” key to select “ON” or “OFF” that can turn on or off the Bluetooth module (If there is no Bluetooth module in the device, the operation is invalid).

(3) Time setting

Under (Settings) interface, select “Time” to enter (Time setting) interface as shown in Fig.21. Select “Minute” to enter (Minute setting) interface, as shown in Fig.22. Press “Up” or “Down” key to change the value (long pressing is available), then press “Confirm” key to return to (Time setting) interface.

The operation of “Hour”, “Day”, “Month”, “Year” is similar to the “Minute”. The “Week” will be calculated according to “Year”, “Month” and “Day”, which does not need to set manually. Then select “Exit” to return to (Settings) interface.




Figure 21 Time setting interface




Figure 22 Minute setting interface

(4) Calibration

Under (Settings) interface, select “Calibration” to enter (Calibration setting) interface as shown in Fig.23. Select 2L or 3L based on the volume of syringe, then enter to (Calibrate) interface as shown in Fig.24.



Figure 23 Calibration setting interface




Figure 24 Calibrate interface

Under (Calibrate) interface, push the syringe once, the device will display “REPEAT”, then push the syringe once again. After twice correct continuous operation, the calibrating will be succeed, and the device will display “OK!”. Finally the interface will jump to the former interface before calibration (The former interface: If the device is calibrated after measurement completed, it will return to (Settings) interface; if calibrated before measurement completed, it will return to (Testing) interface.).

If the device displays “Error! Please repeat”, it indicates something wrong with the operation, please repeat the calibrating until succeeded. If the device displays “Select right volume”, please confirm whether the volume of syringe and calibration selection is accordant, then repeat the calibrating until succeeded. If you need to stop calibrating, just press the “Confirm” key to exit to the former interface before calibration.

Under (Calibration setting) interface, select “Adjust” to enter (Adjusting) interface, as shown in Fig.25. Press “Up” or “Down” key to change the value (long pressing is available), then press “Confirm” key to return to (Adjusting confirm) interface, as shown in Fig.26. Selecting “Yes” will save adjusted value, selecting “No” will cancel the setting, then the device will return to (Calibration setting) interface.

Note: The value determines the accuracy of measurement, please do NOT change it randomly. After the turbine has been replaced, calibration shall be applied for inputting parameters of new turbine, which guarantees the accuracy of measurement after turbine replaced.




Figure 25 Adjusting interface




Figure 26 Adjusting confirm interface

Under (Calibration setting) interface, select “Exit” to return to (Settings) interface.

(5) About device

Under (Settings) interface, select “About” to enter (About) interface. User can view device name and software version. Press “Confirm” key to return to (Settings) interface.

(6) Exit

Under (Settings) interface, select “Exit” to return to (Menu) interface.

d.Power off

Under (Menu) interface, select “Power off”, the device will shut down.

Note: If there is no operation within 1 minute, the device will power off automatically.

e.Exit

Under (Menu) interface, select “Exit” to return to (Main interface) . If the measurement is not completed before enter (Main interface) , it will return to (Testing) interface.

6.1.5 Repeated measure

Measurement of the device is repeatable. Long press “Repeated measure” key to enter (Testing) interface. When the memory is full, it will display (Memory full) interface as shown in Fig.27. If you select “Yes”, it will enter (Delete data) interface; if you select “No”, it will enter (Menu) interface.



Figure 27

6.1.6 Charge

There are two kinds of charging methods:

- 1) Connect the device with computer by data line— then the device should be under charging state.
- 2) Connect the device with power supply by power adapter, then the device should be under charging state.

For device charging, connect it with the power where easy to be cut off, after charging completed, unplug the power adapter to cut off from power.

6.1.7 Upload Data

Install PC software into a computer, after that, connect the device with the computer by the equipped USB cable, open the software and turn on the device, then data transmission is available.

6.2 Attention

- Please check the device before using, and confirm that it can work normally.
- Rechargeable lithium battery.
- It is recommended that the device should be measured in room.
- Excessive ambient light may affect measurement accuracy. It includes fluorescent lamp, dual ruby light, infrared heater, direct sunlight and etc.
- Intense activity of the subject or extreme electrosurgical interference may also affect the accuracy.
- Please clean and disinfect the device after using according to the User Manual (7.1).

Chapter7 Maintenance,Transportation and Storage

7.1 Cleaning and Disinfection

Using medical alcohol to wipe the device for disinfecting, nature dry or clean it with clean soft cloth. It's necessary to clean the turbine periodically for accuracy, keep the diaphaneity of the lucency part, and keep it away sundries (such as hair or lesser sediment). Immerse the turbine in disinfectant after use, clean it with clean water and dry standing vertically after soaked a few minutes (but don't make the turbine rinsed with water directly), this type doesn't bring pollution to environment. (Note: The disinfectant is 75% alcohol).

7.2 Maintenance

- 1) Please clean and disinfect the device before using according to the User Manual (7.1).
- 2) Please recharge the battery when the screen shows low-power (the battery power is).
- 3) Recharge the battery soon after the over-discharge. The device should be recharged every six months when it is not regular used. It can extend the battery life following this guidance. If the battery is broken, DO NOT try to maintain it by yourself, please contact us or the local service center.
- 4) The device needs to be calibrated once a year (or according to the calibrating program of hospital). It also can be performed at the state-appointed agent or just contact us for calibration.

7.3 Transportation and Storage

- 1) The packed device can be transported by ordinary conveyance or according to transport contract. The device can not be transported mixed with toxic, harmful, corrosive material.
- 2) The packed device should be stored in room with no corrosive gases and good ventilation. Temperature: -40°C~+55°C; Relative Humidity: ≤95%.

Chapter 8 Troubleshooting

Trouble	Possible Reason	Solution
The device can't finish measurement for a long time, and the data can't be displayed.	The start speed is too low, the device does not measure.	Remeasure according to the user manual.
	The malfunction of the device.	Press "Repeated Measure" key to remeasure, or power off to restart.
The figure is wrong and unorderedly.	The power turned off abnormally.	Delete the current case and remeasure.
	Operation is wrong.	Operate normally according to the user manual.
	The malfunction of the device.	Please contact the local service center.
The device can not be powered on.	Low battery or no power.	Please charge the battery.
	The malfunction of the device.	Please contact the local service center.
The display disappears suddenly.	The device is set to automatic power off when there is no operation in one minute.	Normal.
	The battery is drained away or almost drained away.	Please charge the battery.
The device can not be used for full time after charge.	The battery is not full charged.	Please recharge the battery.
	The battery is broken.	Please contact the local service center.
The battery can not be full charged even after 10 hours charging time.	The battery is broken.	Please contact the local service center.

Chapter 9 Symbols

Symbol	Meanings	Symbol	Meanings
	Refer to instruction manual/booklet.		WEEE (2012/19/EU).
	Hazard or Warning - pay close attention.		European Representative
	Full-power.		Low-power.
	Type BF Applied part.		Measured value goes beyond the limits.
	Status indicator bar.		Fragile, handle with care.
	Atmospheric pressure limit		Humidity limit

	Temperature limitation.		Serial number.
	Keep away from rain.		This way up.
	Date of manufacture.		Manufacturer.
	Turn the turbine clockwise to unlock.		Turn the turbine counterclockwise to lock.
	Charging indicator.		Medical device
	This item is compliant with Medical Device Directive 93/42/EEC of June 14, 1993, a directive of the European Economic Community.		Unique Device Identifier
	Product code		Lot number
	Covering Protection rate		Importated by

Chapter 10 Parameter Introduction

Measured parameters		
Parameter	Description	Unit
FVC	Forced vital capacity	L
FEV1	Forced Expired Volume in one second	L
PEF	Peak expiratory flow	L/s
FEV1%	FEV1/FVC×100	%
FEF25	25% flow of the FVC	L/s
FEF2575	Average flow between 25% and 75% of the FVC	L/s
FEF75	75% flow of the FVC	L/s

Appendix I

Guidance and manufacturer's declaration – electromagnetic emissions-

for SPIROMETER

Guidance and manufacturer's declaration – electromagnetic emission		
The SPIROMETER (SP10) is intended for use in the electromagnetic environment specified below. The customer of the user of the SPIROMETER (SP10) should assure that it is used in such an environment.		
Emission test	Compliance	Electromagnetic environment – guidance
RF emissions CISPR 11	Group 1	The SPIROMETER (SP10) uses RF energy only for its internal function. Therefore, its RF emissions are very low and are not likely to cause any interference in nearby electronic equipment.
RF emission CISPR 11	Class B	The SPIROMETER (SP10) is suitable for use in all establishments, other than domestic establishments and those directly connected to the public low-voltage power supply network that supplies buildings used for domestic purposes.

Guidance and manufacture's declaration – electromagnetic immunity –

for SPIROMETER

Guidance and manufacture's declaration – electromagnetic immunity			
The SPIROMETER (SP10) is intended for use in the electromagnetic environment specified below. The customer or the user of SP10 should assure that it is used in such an environment.			
Immunity test	IEC 60601 test level	Compliance level	Electromagnetic environment - guidance
Electrostatic discharge (ESD) IEC 61000-4-2	±6 kV contact ±8 kV air	±6 kV contact ±8 kV air	Floors should be wood, concrete or ceramic tile. If floor are covered with synthetic material, the relative humidity should be at least 30%.
Power frequency (50/60Hz) magnetic field IEC61000-4-8	3A/m	3A/m	Power frequency magnetic fields Should be at levels characteristic of a typical location in a typical commercial or hospital environment.
NOTE U _i is the a.c. mains voltage prior to application of the test level.			

Guidance and manufacturer's declaration – electromagnetic immunity –

for SPIROMETER (SP10) that are not LIFE-SUPPORTING

Guidance and manufacturer's declaration – electromagnetic immunity			
The SPIROMETER (SP10) is intended for use in the electromagnetic environment specified below. The customer or the user of SPIROMETER (SP10) should assure that it is used in such an environment.			
Immunity test	IEC 60601 test level	Compliance level	Electromagnetic environment - guidance
Radiated RF IEC 61000-4-3	3 V/m 80 MHz to 2.5 GHz	3 V/m	Portable and mobile RF communications equipment should be used no closer to any part of the SPIROMETER (SP10), including cables, than the recommended separation distance calculated from the equation applicable to the frequency of the transmitter. Recommended separation distance $d = 1.17\sqrt{P}$ 80 MHz to 800 MHz $d = 2.33\sqrt{P}$ 800 MHz to 2.5 GHz Where P is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer and d is the recommended separation distance in metres (m). Field strengths from fixed RF transmitters, as determined by an electromagnetic site survey, ^a should be less than the compliance level in each frequency range. ^b Interference may occur in the vicinity of equipment marked with the following symbol:

NOTE 1 At 80 MHz and 800 MHz, the higher frequency range applies.
NOTE 2 These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

- ^a Field strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephones and land mobile radios, amateur radio, AM and FM radio broadcast and TV broadcast cannot be predicted theoretically with accuracy. To assess the electromagnetic environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the SP10 is used exceeds the applicable RF compliance level above, the SP10 should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as reorienting or relocating the SP10.
- ^b Over the frequency range 150 kHz to 80 MHz, field strengths should be less than 3 V/m.

Recommended separation distances between portable and mobile

RF communications equipment and the SPIROMETER (SP10) –

Recommended separation distances between portable and mobile RF communications equipment and the SPIROMETER (SP10)			
The SPIROMETER (SP10) is intended for use in an electromagnetic environment in which radiated RF disturbances are controlled. The customer or the user of the SPIROMETER (SP10) can help prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communications equipment (transmitters) and the SPIROMETER (SP10) as recommended below, according to the maximum output power of the communications equipment.			
Rated maximum output power of transmitter (W)	Separation distance according to frequency of transmitter (m)		
	150 kHz to 80 MHz $d = 1.17\sqrt{P}$	80 MHz to 800 MHz $d = 1.17\sqrt{P}$	800 MHz to 2.5 GHz $d = 2.33\sqrt{P}$
0.01	0.12	0.12	0.23
0.1	0.37	0.37	0.74
1	1.17	1.17	2.33
10	3.70	3.70	7.37
100	11.70	11.70	23.30
For transmitters rated at a maximum output power not listed above, the recommended separation distance d in metres (m) can be estimated using the equation applicable to the frequency of the transmitter, where P is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer. NOTE 1 At 80 MHz and 800 MHz, the separation distance for the higher frequency range applies. NOTE 2 These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.			



Disposal: The product must not be disposed of along with other domestic waste. The users must dispose of this equipment by bringing it to a specific recycling point for electric and electronic equipment.

GIMA WARRANTY TERMS

The Gima 12-month standard B2B warranty applies